



MI-BLPH2

Plastic Tension Handle for 1 3/4" Core



INSTRUCTIONS

1. Insert the handle into the core of the film roll, be sure that you are using a film with a 1.75" core.
2. For optimal use, make sure the handle is completely inserted. It should fit snugly in the roll core.

Visit www.wraptite.com to view our other products.

INDUSTRIAL



JAN/SAN



SAFETY

