

## Instruction Sheet

### MI-BT38



## INSTRUCTIONS

1. To load the dispenser, place the tape roll onto the dispensing spool making sure that you load it with the adhesive side up.
2. Unwind and position the tape so that a couple inches of tape are hanging off the front of the dispenser overtop of the open gear slot with the adhesive side up.
3. To operate, twist bag and lineup the desired section of the bag you intend to seal over the slot.
4. Apply downward pressure through the gear slot to apply the tape and continue over the lever to cut the tape.