



Certified to ISO 9001:2015





MI-BT38

Bag Tape Dispenser



INSTRUCTIONS

- 1. To load the dispenser, place the tape roll onto the dispensing spool, making sure that you load it with the adhesive side up.
- 2. Unwind and position the tape so that a couple inches of tape are hanging off the front of the dispenser, on top of the open gear slot with the adhesive side up.
- 3. To operate, twist bag and lineup the desired section of the bag you intend to seal over the slot.
- 4. Apply downward pressure through the gear slot to apply the tape and continue over the lever to cut the tape.

Visit www.wraptite.com to view our other products.

info@wraptite.com

1.888.WRAPTITE (972.7848)