



MI-GW1520

Ergonomic
Screw Lock Dispenser
for 15"-20" Coreless
Pre-Stretch Wrap



INSTRUCTIONS

1. To load your dispenser, unscrew the two halves of the dispenser from themselves by rotating counterclockwise.
2. Next, slide your coreless film roll onto either of the two halves.
3. Now that the roll is loaded, insert the remaining half into the film roll and screw it back into the other half rotating clockwise.
4. Tighten or loosen your dispenser as needed based on the width of the film roll being used.

Visit www.wraptite.com to view our other products.

INDUSTRIAL



JAN/SAN



SAFETY



info@wraptite.com

1.888.WRAPTITE (972.7848)