



Instruction Sheet

MI-GWNW3



INSTRUCTIONS

1. Take 3" coreless banding film and place onto the core of the dispenser handle. Push down until the roll is completely secured on the dispenser. (The roll should fit snugly on the dispenser.)
- 2.

888-WRAPTITE (972-7848)

www.wraptite.com

info@wraptite.com