



MI-GWNW3

Extended Core Dispenser for 3" Coreless Banding Film



INSTRUCTIONS

1. Take 3" coreless banding film and place onto the core of the dispenser handle. Push down until the roll is completely secured on the dispenser. (The roll should fit snugly on the dispenser.)

Visit www.wraptite.com to view our other products.

INDUSTRIAL



JAN/SAN



SAFETY



info@wraptite.com

1.888.WRAPTITE (972.7848)