

Instruction Sheet

MI-HS3



INSTRUCTIONS

1. Place each of the two hand saver units into both ends of the film roll.
2. Make sure to fully secure them to the roll by sliding them completely into the film roll core.
3. Be sure to align the hand grips on each side for optimal use.

888-WRAPTITE (972-7848)

www.wraptite.com

info@wraptite.com