



## Instruction Sheet

### MI-HS3Y

Insert This End into Film Core



## INSTRUCTIONS

1. Place each of the two hand saver units into both ends of the film roll.
2. Make sure to fully secure them to the roll by sliding them completely into the film roll core.

888-WRAPTITE (972-7848)

[www.wraptite.com](http://www.wraptite.com)

[info@wraptite.com](mailto:info@wraptite.com)