



Instruction Sheet

MI-WPH3



Insert This End Into
Film Core

INSTRUCTIONS

1. Insert the handle into the core of the film roll, be sure that you are using a 3" core film.
2. For optimal use, make sure the handle is completely inserted, it should fit snugly in the roll core.

888-WRAPTITE (972-7848)

www.wraptite.com

info@wraptite.com