




Certified to ISO 9001:2015








INSTRUCTIONS

- 1. To load, place 2" width tape roll onto tape wheel and push fully onto the wheel. Be sure to load the tape with the adhesive side down.
- 2. Unroll approximately 5" of tape and thread the tape through the metal holding plate and the plastic roller.
- 3. Tighten or loosen the tension knob located on the tape wheel for optimal performance.
- 4. To operate, glide the dispenser along the desired area while applying downward pressure.
- 5. When you are done dispensing, tilt the dispenser upward and apply pressure to cut the tape to length.

Visit www.wraptite.com to view our other products.



info@wraptite.com

1.888.WRAPTITE (972.7848)